

KICKITTM

BILLET ALUMINUM KICKSTANDS

Thank you for your purchase, we are confident that you will be pleased with the quality of our product.

Instructions: KAWASAKI 12-14 KX450F (PMB-01-2009)

To install your new kickstand:

1. Remove the left foot peg and bracket.
2. Install the kickstand under the left foot peg bracket using the stock bolt on the bottom and the new supplied bolt on the top, we recommend using a removable thread-locking agent on the bolts.
3. Make sure that you tighten the foot peg bracket bolts to the correct torque as specified in your owner's manual.
4. Once the kickstand has been installed, slowly move the kickstand through its motion to ensure it doesn't catch on anything. If the left rear side panel has been bent in the plastic may need to be heated with a heat gun and bent or pulled out to avoid interfering with the kickstand.
5. Re-install the foot peg.
6. Periodically check the foot peg mounting bolts, and kickstand pivot bolt for tightness.

Maintenance:

Clean and lubricate the kickstand pivot area after each ride. We recommend using a penetrating lube, such as WD-40. If necessary, you can remove the back cover plate for additional cleaning.

CAUTION: We do not recommend starting the bike with the kickstand down, as this may cause damage to the kickstand.

Manufactured and Distributed by:

Pro Moto Billet
11461 Lone Star RD
Nampa ID 83651
208-466-4762

Parts List:

1-Kickstand
1-10x30 Modified
Socket-head Bolt

Check out our Spark Arrestor Endcaps, Billet Cargo Racks, Shark Fins and other billet accessories at...

