



Instructions – PMB-01-1002

Thank you for your purchase! We are confident that you will be pleased with the quality of our product.

Parts List:

1-Kickstand

2-10x40 SH Modified

NOTE: We recommend using a thread-locking agent on all bolt threads.

To install your new kickstand:

1. Remove the left footpeg and bracket.
2. Install the kickstand under the left footpeg bracket using the new 10x40mm socket head bolts. We recommend using a removable thread-locking agent on the bolts. Check to make sure that the weld on the frame is not interfering with the kickstand mount, if necessary, file the weld and bracket to allow for proper fit. It might be necessary to remove the footpeg from the bracket in order to remove and install the new bolts.
3. Re-install the footpeg.
4. Make sure that you tighten the footpeg bracket bolts to the correct torque specification.
5. Periodically check the footpeg mounting bolts for tightness.

To prevent damage:

- Clean and lubricate the kickstand pivot area after each ride! We recommend using a penetrating lube, such as WD-40. If necessary, you can remove the back cover plate for additional cleaning.
- Carefully position kickstand up and down.
- Do not start/sit on bike with the kickstand down.