

Instructions – PMB-01-2001

Thank you for your purchase! We are confident that you will be pleased with the quality of our product.

Parts List:

1-Kickstand

1-8x30 FH

1-8x70 SH

1-8x10x5 Spacer

NOTE: We recommend using a thread-locking agent on all bolt threads.

To install your new kickstand:

1. Remove the lower chain roller and bolt; make sure you keep track of the order of the small parts for re-assembly. Remove the sub-frame to main-frame bolt.
2. Install the provided sub-frame bolt spacer into the sub-frame bolt hole.
3. Install kickstand on the bike using the 8x30mm flat head bolt. Re-Install the chain roller using the 8x70mm socket head bolt, if the bolt is too long cut it off with a hacksaw or die grinder. We recommend using a removable thread locking agent on the bolts.
4. Make sure that you tighten all bolts to the correct torque.
5. Periodically check the kickstand pivot bolt for tightness.

To prevent damage:

- Clean and lubricate the kickstand pivot area after each ride! We recommend using a penetrating lube, such as WD-40. If necessary, you can remove the back cover plate for additional cleaning.
- Carefully position kickstand up and down.
- Do not start/sit on bike with the kickstand down.