

Instructions – PMB-01-3009

Thank you for your purchase! We are confident that you will be pleased with the quality of our product.

Parts List:

- 1-Kickstand
- 1-M8 Lock Nut
- 1-8x80 FH
- 1-8x30 FH
- 1-Spacer

NOTE: We recommend using a thread-locking agent on all bolt threads.

To install your new kickstand:

1. Place bike on a center stand.
2. Remove the lower chain guide and bolt making sure you keep track of the order of the small washers for re-assembly.
3. Remove the lower sub-frame to main-frame bolt.
4. Install the kickstand onto the bike using the 8x30mm flat head bolt at the sub-frame to main-frame bolt location with the supplied spacer between the kickstand and sub-frame. Do not tighten yet.
5. Install the 8x80mm flat head bolt thru the lower kickstand mounting hole into the stock triangle stand hole.
6. Now tighten bolts.
7. Re-install the lower chain guide and washers on the end of the 8x80mm flat head bolt.
8. Install the 8mm lock nut on the end of the 8x80mm flat head bolt. (see Figure 1)
9. Periodically check the kickstand leg pivot pin and all mounting bolts for tightness.

To prevent damage:

- Clean and lubricate the kickstand pivot area after each ride! We recommend using a penetrating lube, such as WD-40. If necessary, you can remove the back cover plate for additional cleaning.
- Carefully position kickstand up and down.
- Do not start/sit on bike with the kickstand down.

Figure 1

