

Instructions – PMB-01-2007

Thank you for your purchase! We are confident that you will be pleased with the quality of our product.

Parts List:

1-Kickstand
1-Bracket
1-8x80 SH
1-6x25 FH
1-6x20 FH
4-8mm Flat Washers

NOTE: We recommend using a thread-locking agent on all bolt threads.

To install your new kickstand:

1. Put the bike on a stand.
2. Remove the left footpeg.
3. Remove the lower chain roller.
4. Place lower hole on kickstand over the chain roller bolt hole, insert the 8x80 socket head bolt.
5. Loosely install clamping bracket with the lower bolt (6x20 flat head) and upper bolt (6x25 flat head).
6. Re-install stock chain roller components and tighten. (Figure 1)
7. Tighten the two clamping bracket bolts starting with the lower one first. (Figure 2)
8. Check the amount of clearance between the kickstand leg and the swingarm. If more clearance is necessary, slightly loosen the upper bolts, and add an 8mm flat washer onto the chain roller bolt behind the lower kickstand mounting tab. 4 flat washers are provided so you can adjust it to your liking. When proper clearance is achieved, tighten all bolts.
9. Re-install left footpeg.

To prevent damage:

- Clean and lubricate the kickstand pivot area after each ride! We recommend using a penetrating lube, such as WD-40. If necessary, you can remove the back cover plate for additional cleaning.
- Carefully position kickstand up and down.
- Do not start/sit on bike with the kickstand down.

Figure 1




Figure 2

